



Instructions for Hidden Bracket Installation

- ✓ Hidden Brackets must be mounted directly on to timber.
- ✓ Remove any gib from the timber stud before mounting
- ✓ Place the bracket in the position required
- ✓ Fix bracket to stud with screws at least 50mm long making sure bracket is very secure.
- ✓ Drill hole into shelf side where bracket is to be mounted.
- ✓ Drill hole to be 10 mm X 122 mm deep
- ✓ Place shelf over bracket making sure secure

Cliff Hanger Shelving Ltd accepts no responsibility for any damage caused by installation and use of this product.